

# Operating instructions for: net4web-Displaystick for all GoPro-Hero cameras with wifi

# net4web

net4web • Albrecht-Dürer-Str. 6 • D-40764 Langenfeld  
www.net4web.de • info@net4web.de • ☎ 02173-202 7007

## System requirements:

You will need a GoPro-Hero action camera with integrated wifi. This camera should be linked to your smartphone through the free GoPro-App. To find out how to link camera and smartphone, please read the manual of your GoPro-Hero: <https://gopro.com/support/articles/how-to-pair-the-camera-with-the-gopro-app>

## Installation:

First place one spring ring on each one of the three 1/4" screws. Screw the retaining plate onto the handle using the hole in the middle. Next screw the GoPro mount to one of the outer holes of the retaining plate. The smartphone mount should be screwed to the remaining outer hole of the retaining plate (see photo 1). Mount the underwater housing of your GoPro-Hero onto the GoPro mount and fix the housing using the thumbscrew. Plug your smartphone into the smartphone mount.

Make sure the smartphone fits safely and that no operating buttons are clamped. Position the handle, the GoPro and the smartphone the way it seems most comfortable/useful to you. Now fix the three screws using the hex-wrench. Tighten the screws, so the spring ring is pressed about halfway (see photo 2). This way your GoPro-Hero is optimally secured.

Now your net4web-Displaystick is ready for use. Your switched on GoPro can now be controlled using your smartphone. The size of the retaining plate allows a battery change without needing to dismantle everything (see photo 3). For this, you simply need to loosen the thumb screw a little bit, so you can tilt the housing forward. Now you can open the housing and take out the camera for a battery change.

Now the installation is complete and you can point your arm into the direction, you want to film.

If you turn the camera around and mount the smartphone mount to the bottom, you will be able to use the net4web-Displaystick as a selfie stick as well (see photo 4).

Without the handle, you can screw the net4web-Displaystick onto almost every tripod that provides a 1/4" adaptor (see photo 5).

In case you would like to use your net4web-Displaystick underwater as well, please do not forget to use a suitable waterproof smartphone. In every case, you should rinse all parts thoroughly with freshwater after the use in saltwater and leave them to air dry.

At the bottom of the net4web-Displaystick you will find a 3/8"-thread. Onto this, you can screw additional equipment, such as a film lamp or a microphone (see photo 6). We offer a film lamp in our online-shop ([www.net4web.de](http://www.net4web.de)) as a kit including all small parts.



Photo 1




Photo 2



Photo 3



Photo 5

Photo 4



Photo 6

# Scope of delivery:

**net4web-Displaystick**  
**EAN: 0701098440104**

- 1 grip black
- 1 smartphone support
- 1 Mounting sheet metal
- 1 tripod support with screw
- 3 1/4" screw
- 3 spring ring
- 1 hex-wrench
- 1 instruction

Delivery excludes camera, housing, smartphone and tripod.

All photos are examples and are not true to scale.

Copyright © 2016 by net4web • Langenfeld  
All rights reserved.

Visit us on:  
<https://www.net4web.de>



Grip

Smartphone support




1/4" screw



spring ring



3/16 Zoll  
hex-wrench



Mounting sheet metal



Tripod support with screw